




**ACCESSOIRES
ACCESSORIES
ZUBEHÖR**




A532
Thermostat à distance
Remote thermostat
Fernthermostat



A614
Bases pression
Low pressure
Niederdruckventil




A317
Kit de fixation sur barrière
Mounting set on fences
Satz für Gitter



C162
Câble chauffant 24V/22W
Heating cable 24V/22W
Heizkabel 24V/22W




A333
Kit anti-gel 24V - 80W
Frost protection set 24V - 80W
Frostschutz-Set 24V - 80W



***Recommandée : 3 Bar (43.5 PSI)**
Recommended
Empfohlen

Max : 6 Bar (87 PSI)

Pression-Pressure Wasserdruck	Débit-Water flow Wasserdurchfluss
1 Bar 14.5 PSI	16 L/mn 4.21 USG/mn
2 Bar 29 PSI	26 L/mn 6.84 USG/mn
3 Bar* 43.5 PSI	32 L/mn 8.42 USG/mn
4 Bar 58 PSI	36 L/mn 9.47 USG/mn






A501
Transformateur 230/24V - 100VA - 400VA
Transformer 230/24V - 100VA - 400VA
Transformator 230/24V - 100VA - 400VA

N° 4890470 - 03/20

LA BUVETTE®

Parc d'activités Ardennes Emeraude
Rue Maurice Perrin - CS 50749 - Tornées
F-08013 CHARLEVILLE-MEZIERES Cedex FRANCE
TEL : 03.24.52.37.20 - FAX : 03.24.52.37.24
Int : 03.32.45.23.24
S.A.V. : 03.24.52.37.27 - FAX : 03.24.52.37.24
Internet : www.labuvette.com
e-mail : commercial - labuvette.com
sav - labuvette.com

**EASY-STALL 45
EASY-STALL 100
2425 - 2426**




1 EASY-STALL 45 → 10 Vaches allaitantes - Dairy cows - Milchkühe
→ 15 Vaches allaitantes - Cattle - Rinder

1 EASY-STALL 100 → 20 Vaches allaitantes - Dairy cows - Milchkühe
→ 30 Vaches allaitantes - Cattle - Rinder

!
- Utiliser obligatoirement 4 points de fixation
- Must use 4 anchors
- Sie müssen die 4 Befestigungspunkte benutzen

**REGLAGE DU NIVEAU D'EAU
WATER LEVEL ADJUSTMENT
WASSERSTANDSANPASSUNG**



700mm - 900mm
(28" - 35")

485mm - 685mm
(19" - 27")